



### System Requirements

The following is a list of the minimum requirements for operating PSS<sup>®</sup>NETOMAC.

#### Hardware:

- PC or notebook

- CPU x86 compatible
- 256 MB RAM
- 500 MB of free disk space
- graphics card with a resolution of at least 1024 x 768 pixels, 16 bit
- suitable monitor or LCD display

- Keyboard and mouse

#### Operating Systems supported:

- Windows 95, 98
- NT 4.0 SP 3 (or higher)
- Windows 2000
- Windows XP

Published by and copyright © 2009:  
Siemens AG  
Energy Sector  
E D SE PTI  
Freyeslebenstrasse 1  
91058 Erlangen, Germany

[www.siemens.com/energy/power-technologies](http://www.siemens.com/energy/power-technologies)

Siemens Energy, Inc.,  
Power Distribution, T&D Service Solutions  
Siemens Power Technologies International  
400 State Street  
PO Box 1058  
Schenectady, NY 12301-1058

Siemens Transmission and Distribution Ltd  
PTI  
Sir William Siemens House, Princess Road  
Manchester, M20 2UR  
United Kingdom

For more information, please contact  
our Customer Support Center.  
Phone: +49 180 524 70 00  
Fax: +49 180 524 24 71  
(Charges depending on provider)  
E-mail: [support.energy@siemens.com](mailto:support.energy@siemens.com)

Power Distribution Division  
Printed in Germany  
Printed on elementary chlorine-free  
bleached paper.

All rights reserved.  
Trademarks mentioned in this document  
are the property of Siemens AG, its affiliates,  
or their respective owners.  
Subject to change without prior notice.  
The information in this document contains general  
descriptions of the technical options available,  
which may not apply in all cases.  
The required technical options should therefore be  
specified in the contract.

SWNM80-EN-200905